



Table of Contents	Page
General Notes and Tools Required_____	2-3
Assemble Shelves with Coat Hooks/Coat Rods_____	4
Fastening Chart_____	5
Knock Down Locker Assembly (Banks of Three)_____	6-12
Appendix A: Dress End Panel_____	12
Appendix B: Starter Trim & Expansion Trim_____	13
Appendix C: "U" Filler Panel_____	14
Appendix D: Flat Top Corner_____	14
Appendix E: Box Bases_____	15-16
Appendix F: Z Bases_____	17
Appendix G: Slope Tops_____	18-20
Appendix H: Plenum Panels_____	20
Appendix I: Recess Trim _____	21
Appendix J: Locker Bench_____	21
Appendix K: 6 Tier Lockers (Frame Stiffener)_____	22
Appendix L: Built In Master Locks_____	22

Tools Required

- Rivet gun
- Screwdriver - Robertson or Phillips (if using nuts and screws).
- 1/4" (6mm) & 7/32" (5mm) drill bit - only required if installing optional items.
- Scratch awl (to insert into holes to align panels properly).
- 11/32" nut driver (to attach hooks if using nuts and screws)

General Notes

These instructions are for the assembly of Hadrian lockers only. For instructions on positioning the lockers and securing them in place, refer to the site blueprints.

Basic procedure for assembling Hadrian lockers:

1. Assemble the chassis. Connect the sides, backs and shelves for a bank of lockers.
2. Attach the door and frame assemblies to the chassis.
3. If using optional box bases, assemble the bases for the locker bank and attach to the lockers. If using optional Z-base, anchor it to floor in appropriate position.
4. Place the lockers in their correct position and level.
5. Secure lockers to the wall blocking with fasteners.
6. Add the optional slope top or trim if required.

Assembly instructions for Gladiator athletic lockers differ only in the fact that coat hooks are installed through pre-punched holes in the locker backs and sides (As opposed to under the shelves in Emperor Corridor lockers).

Lockers should not be stored outside and should always be kept dry.

It is the distributor’s responsibility to supply end-users with maintenance and warranty information.

Fasteners Provided

Rivets

or

Nuts & Bolts

Emperor Locker Rivet
Part# 790025



Gladiator Locker Rivet
Part# 790026

8-32 Flat Locker Screw
Part# 780015

8-32 Hex Locker Nut
Part# 780020



Recommended Safety Equipment

Safety Glasses



Safety Gloves



Safety Shoes



Hard Hat




Installation Manual for Metal Emperor & Gladiator Lockers

Assemble Shelves with Coat Hooks

Attach coat hooks as shown with rivets or bolts.

Note: Coat hooks are provided with single tier and double tier lockers only.

Optional double prong coat hooks are available. Shelf requires two holes in the center middle of the shelf. Pre-prepared holes is by request only.




Preview	Part Number	Description
	780040	Locker Coat Hook

Assemble Shelves with Optional Coat Rods

Attach coat rods as shown with rivets or bolts.

Note: Coat rods can be provided with single tier and double tier lockers only.

Optional Gladiator coat rod brackets are available. Side panels requires two holes for mounting coat rod brackets. Pre-prepared holes is by request only.



Preview	Part Number	Description
	7822**	Coat Rod
	782295	Coat Rod Assembly - Emperor

Fastener Chart

Use this chart to determine where to add fasteners while attaching side panel to the back panel.

A - indicates to add a fastener **B** - indicates to leave hole open for attaching shelf **C** - indicates to leave hole open for attaching banks

72" (1829mm) High Lockers	Single Tier	Double Tier	Three Tier	Four Tier	Six Tier
	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Intermediate</div> </div>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Intermediate</div> </div>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Intermediate</div> </div>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Intermediate</div> </div>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Intermediate</div> </div>



60" (1524mm) High Lockers	Single Tier	Double Tier	Three Tier	Four Tier	Five Tier
	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Intermediate</div> </div>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Intermediate</div> </div>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Intermediate</div> </div>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Intermediate</div> </div>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Intermediate</div> </div>

Installation Manual for Metal Emperor & Gladiator Lockers

STEP 1: Assemble Backs and Sides

With back flat side down, attach side panel. The single row of holes indicates the rear of the side panel.


See fastening chart on page 5



STEP 2: Position Top, Bottom, and Shelf.

Ensure shelves are oriented as shown (i.e.: "hemmed" edge towards the front of the locker).

Note: shelves, tops and bottoms are interchangeable



Installation Manual for Metal Emperor & Gladiator Lockers


STEP 3: Position Top, Bottom, and Shelf.

With back flat side down, attach side panel. The single row of holes indicates the rear of the side panel.

See fastening chart on page 5

Note:

Fasten location shown is based on a single tier intermediate side. See fastening chart for other locations.




STEP 4: Position Top, Bottom, and Shelf.

Ensure shelves are oriented as shown (i.e.: "hemmed" edge towards the front of the locker).

Note: shelves, tops and bottoms are interchangeable

A - Add fastener.




Installation Manual for Metal Emperor & Gladiator Lockers

Repeat Steps 3 & 4 as Needed

With back flat side down, attach side panel. The single row of holes indicates the rear of the side panel.


See fastening chart on page 5



STEP 5: Fasten End Side

With back flat side down, attach side panel. The single row of holes indicates the rear of the side panel.

See fastening chart on page 5



Installation Manual for Metal Emperor & Gladiator Lockers

STEP 6: Attach Frame Assemblies

Place one end of frame assembly over the chassis and rotate flat, ensuring proper fit with side panels.

Ensure fronts of all frame assemblies are flush.

Note: For corner (End) units, fasten all remaining holes.


If the optional dress end panel is to be used, attach locking strip now. See page 12

If optional expansion trim is to be used, attached expansion trim now. See page 13

If optional "U" filler is to be used, attached "U" filler now. See page 14

If optional recess trim is to be used, attach side trim now. See page 14

Six tier lockers require a frame stiffener. See page 22



A - Add fastener.

C - Leave open for attaching additional banks.


Note: For corner (End) units, fasten all remaining holes.

STEP 7: Attach Frame Assemblies

Place one end of frame assembly over the chassis and rotate flat, ensuring proper fit with side panels.

Ensure fronts of all frame assemblies are flush.

Six tier lockers require a frame stiffener. See page 22




Installation Manual for Metal Emperor & Gladiator Lockers

STEP 8: Attach Frame Assemblies

Place one end of frame assembly over the chassis and rotate flat, ensuring proper fit with side panels.

Ensure fronts of all frame assemblies are flush.

*Six tier lockers require a frame stiffener.
See page 22*



A - Add fastener.

STEP 9: Attach Frame Assemblies

Repeat Steps 7 & 8 as needed.

Place one end of frame assembly over the chassis and rotate flat, ensuring proper fit with side panels.

Ensure fronts of all frame assemblies are flush.

Note: For corner (End) units, fasten all remaining holes.


If the optional dress end panel is to be used, attach locking strip now. See page 12

If optional expansion trim is to be used, attached expansion trim now. See page 13

If optional "U" filler is to be used, attached "U" filler now. See page 14

If optional recess trim is to be used, attach side trim now. See page 21

*Six tier lockers require a frame stiffener.
See page 22*



A - Add fastener.

C - Leave open for attaching additional banks.


*Note: For corner (End) units,
fasten all remaining holes.*

Installation Manual for Metal Emperor & Gladiator Lockers

STEP 10: Fasten Lockers to Wall


Stand lockers up right and position against the wall. Fasten every second locker to the wall, using 2 screws with anchors. Dimensions shown is based on a 72" high locker.

Note: Blocking and fasteners by others.



STEP 11: Fasten Banks

Attach banks of lockers together with rivets or nuts and bolts. Follow Step 10 for fastening to the wall.




Installation Manual for Metal Emperor & Gladiator Lockers

STEP 12: Fasten Number Plates

Attach number plates to the lockers with rivets. (Provided).


Number sequence is provided by end-user.



Appendix A: Dress End Panel

Attach locking strip while frame assembly is being attached. The front of the locking strip must be slightly behind the front of the frame assembly. The locking strip must present an opening to the locker front in order to accommodate the dress end.


Once lockers are erected, slide dress end panel over locking strip until back bend is behind locker. Drill three 7/32" (6mm) holes, evenly spaced, through the lip of the dress end panel and into rear of locker. Secure with rivets.



Installation Manual for Metal Emperor & Gladiator Lockers


Appendix B.1: Starter Trim

Fasten expansion trim to the locker jamb as noted in steps 8 & 9. Pages 9 & 10



Appendix B.2: Starter Trim


Fasten Starter Trim to the wall, with a minimum of 5 screws. (supplied by others)



Appendix B.3: Starter Trim

Fasten Starter Trim to the wall, with a minimum of 5 screws. (supplied by others)


24" x 24" Flat Top or Slope Top
(Cut in field to size required)



Installation Manual for Metal Emperor & Gladiator Lockers

Appendix C: "U" Filler Panel


Fasten "U" filler to locker jamb with a minimum of 5 fasteners.



Appendix D: Flat Top Corner

Attach locking strip while frame assembly is being attached. The front of the locking strip must be slightly behind the front of the frame assembly. The locking strip must present an opening to the locker front in order to accommodate the dress end.

Once lockers are erected, slide dress end panel over locking strip until back bend is behind locker. Drill three 1/4" (6mm) holes, evenly spaced, through the lip of the dress end panel and into rear of locker. Secure with rivets.




Installation Manual for Metal Emperor & Gladiator Lockers

Appendix E.1: Box Bases

Assemble a base long enough to match the bank of lockers.

Base sides are positioned inside the front and back. One side is shared between adjacent boxes.


Front panels must be flush.



Appendix E.2: Box Bases

Fit the sides of the base inside the locker side panels.


Holes are provided at each end of the side for fastening Box Base. When installed correctly, the base will be approximately 3/8" (10mm) from the back of locker. This prevents interference with the floor molding.



Installation Manual for Metal Emperor & Gladiator Lockers

Appendix E.3: Box Bases


Install base corners where there are gaps due to corner conditions, end conditions and or filler/trim condition.



Appendix E.4: Box Bases

Install back to back base trim when you have back to back conditions.

Note: Base trim is to be cut to size in field.



Installation Manual for Metal Emperor & Gladiator Lockers

Appendix F.1: Z Base

Fasten Z-base to floor. Establish hole locations from wall using the following:


Hole Locations

12" (305mm) Deep Lockers – 9 ¼" (235mm) from wall
 15" (381mm) Deep Lockers – 12 ¼" (311mm) from wall
 18" (457mm) Deep Lockers – 15 ¼" (387mm) from wall
 21" (535mm) Deep Lockers – 18 ¼" (463mm) from wall
 24" (607mm) Deep Lockers – 21 ¼" (540mm) from wall

Use part number 780027 – ¼" x 1 ¾" hex concrete screws, for all floor and wall mounting.

Use part# 790025 – rivet, for all base to base hardware connections.

Note: Continuous Z Base is to be cut to size in field.







Appendix F.2: Z Bases

Notes:

Use an end base at every other joint to provide stabilization for the base system.


For back-to-back lockers, anchor a 12" (305mm) expansion trim to the floor between the rows of lockers. Expansion trim is to be cut to size in field. Fasten locker backs through the 12" expansion trim. Hadrian also recommends the use of wood blocking on floor (by others) to support the locker backs.



Installation Manual for Metal Emperor & Gladiator Lockers

Appendix G.1: Slope Tops – Support Clips

Prepare slope top support clip, by bending the support clip at the correct locker depth (noted on clip). Bend the support clip to 90° by hand. Space support clips evenly and fasten to locker top.




Appendix G.2: Slope Tops

See appendix G.3 for details.

Slope top heights for different locker depths

12" Deep Lockers / 4" Slope Top Height
 15" Deep Lockers / 5" Slope Top Height
 18" Deep Lockers / 6" Slope Top Height
 21" Deep Lockers / 7" Slope Top Height
 24" Deep Lockers / 8" Slope Top Height



Installation Manual for Metal Emperor & Gladiator Lockers


Appendix G.3: Slope Tops

Slide Slope Top onto top of locker frame and support clip as shown in Step 1 & 2.


Insert Splice Plate for long runs of Slope Top. Splice Plate to be installed at each Slope Top end, as shown in Step 3.

Fasten End Gusset to locker, as shown in Step 4.


Step 1 - Clip slope top to door frame.




Step 2 - Clip slope top to support clip.



Step 3 - Slide on splice assembly.




Step 4 - Install end gusset and fasten.



Appendix G.4: Slope Tops – Corner

Run one end of the Slope Top flush against the wall. Use Slope Top Corner at the connection with the adjacent Slope Top.


Note the direction of the Slope Top Corner provided prior to layout of Slope Top.



Installation Manual for Metal Emperor & Gladiator Lockers

Appendix G.5: Slope Tops – Back to Back

Prepare slope top support clip by bending the support clip at the correct locker depth (noted on clip). Bend the support clip to 90° by hand. Space support clips evenly and fasten to locker top back to back, as shown in the detail. Follow Appendix G.3 for slope top installation.





Appendix H.1: Plenum Panels

Fasten head trim to bulk head and shelf trim to the top of lockers, flush to the front of the locker. Some field cutting may be required.

Appendix H.2: Plenum Panels

Slide Plenum panel up into the top channel and then in and down into the bottom channel. Some field cutting may be required.

Preview	Part Number	Description
	790025	Rivet
	610072	#12 x 1 3/4" Screw
	610053	Plastic Anchor




Installation Manual for Metal Emperor & Gladiator Lockers

Appendix I: Recess Trim

Attach side trim to the locker door jamb during steps 6 & 9 of the assembly instructions. See page 9 & 10

Position top trim and fasten with trim clips every 12". Use a splice plate to join top trim pieces.


Note: Top trim to be cut to size in field.



Appendix J: Benches

Aluminum pedestals are painted to match the locker door and frame color.


Benches that are 8' and larger require 3 bench pedestals per bench.



Installation Manual for Metal Emperor & Gladiator Lockers


Appendix K: Six Tier Frame Stiffener

Install the frame stiffener under the middle shelf. The stiffener should be installed during locker assembly steps 6, 7 & 8.



Appendix L: Built in Combination Locks (Master Lock Only)

Follow the Master Lock installation instructions that were provided with the locks. Hadrian supplies a keeper, which is required as shown below when installing the lock.



Appendix L: Built in Key Locks (Master Lock Only)

Follow the Master Lock installation instructions that were provided with the locks. Hadrian supplies a keeper, which is required as shown below when installing the lock.

